

A Generic Sauna Room **Assembly Manual**



Classic Bench



Piano Bench



Wave Bench


TABLE OF CONTENT


Parts List Exterior and Interior	3
Parts List Interior (L-type Bench)	4
Parts List Interior (Wave-type Bench)	5
Screws for Room Exterior and Interior	6
Wall Assembly	7
Ceiling Assembly	
Moulding Installation Sequence	10
Interior Furnishes Assembly	12
Interior Furnishes Assembly (Bench Support)	14
Interior Furnishes (Bench Covers)	15
Electrical Layout	
Sauna Maintenance	

NOTE!

Warranty is not covering damages which are caused by installing, using or maintenance of contrary guidelines in this manual. Contact for your retailer in warranty questions.


Parts List Exterior






- . Ceiling Assembly
- 2. Wall Elements
- 3. Exterior Mouldings
- 4. Top Exterior Mouldings
- 5. Bottom Exterior Mouldings
- 6. Main Base Frame
- 7. ABS Bolt Leveler
- 8. Door Set


Parts List Interior






- 1. Back Rest
- 2. Top Bench Cover
- 3. Top Bench Frame
- 4. Bench Siding
- 5. Lower Bench Cover
- 6. Lower Bench Frame
- 7. Bench Supports
- 8. Flooring
- 9. Collapsible heater guard
- 10. Internal Mouldings
- 11. Internal Top Mouldings
- 12. Internal Bottom Horizontal Mouldings


Parts List Interior (L-type Bench)





Parts List Interior (Wave-type Bench)

*For room with wave design benches.







- . Upper Bench Cover
- 2. Upper Bench Frame
- 3. Upper Bench Support
- 4. Lower Bench Cover
- 5. Lower Bench Frame
- 5. Lower Bench Support
- 7. Bench Siding
- 8. Collapsible heater guard

Parts List Interior (L-type Wave Bench)


*For room with larger wave design benches.






- 1. Back Rest
- 2. Upper Bench Cover
- 3. Upper Bench Frame
- 4. Upper Bench Support
- 5. Lower Bench Cover
- 6. Lower Bench Frame
- 7. Lower Bench Support
- 8. Bench Siding

Screws for Room Exterior





Screws for Room Interior




Wall Assembly

Ol Connect base frames according to their corresponding numbers.









Wall Assembly

Attach wall panels according to their label. Take note of the grooves direction




Secure walls with cam locks.




Before moving on to securing the next wall element, make sure that both cam locks are properly secured.


O5 Secure door jamb with screws then cover with screw caps.



Ceiling Assembly


Attach ceiling assembly via tongue to Groove.






Check that the ventilation hole is in the right position (refer to plan drawing for ventilation

location).



Attach all mouldings in sequence. (External, internal, top and bottom).




At this stage make sure all internal mouldings are attached as it will be hard to do once the benches are installed.


Moulding Installation Sequence



From the inside, follow the sequence below.










Interior Furnishes Assembly

Attach bench support at suggested height with screws, then place over the bench frame assembly and screw to wall.



09 Attach heater guard, back rest and bench siding.











Piano Bench




Wave Bench



On large sauna rooms, the flooring needs to be placed first as it will be hard to place inside once the bench supports are installed.


Interior Furnishes Assembly (Bench Support)



Interior Furnishes (Bench Covers)


*For big sauna rooms

Attach upper and lower bench covers, then proceed with the heater guard. Lastly attached the flooring.



Electrical Layout

11 Electrical/Wiring locations.




Electrical Conduit Locations:

- A. For heater and regulating sensor.
- B. For sauna light switch and heater control.
- C. For sauna light.

Wire Installation:

- Install junction / utility box /power controller into the ceiling roof as indicated.
- Insert wires into the electrical conduit designated for thesauna light switch (for NB heaters) or sauna control unit (for NS heaters).
- Insert wires into the electrical conduit designated for theheater (see technical detail). Extra wire jacket is provided for hooking up single wires to the heater. Disregard the extra wire jacket if you are using a rubber cable that is specified in the heater's manual.
- 4. Tapping of wires will be done at the junction box.

Separate Control Installation (NS model heaters only)



A conduit pipe is provided for the control unit.

If wanting to flush the control unit into the wall, cut a hole according to your control unit's specifications. See heater control manual.




Control unit must not be flushed to the wall, near or on the wall where the heater is installed. Use control unit interface holder if necessary.

You can hide the power controller on the top of the sauna room.



Refer to heater control instruction manual for wiring connections.

13 Sensor Installation



Note: Sensor installation is for Separate control heater models only.

A pre-drilled hole for the sensor is provided for separate control heaters.

Sensor is placed directly above the heater. Refer to the heater control instruction manual for the sensor installation.

14 Light Installation



The wall has a pre-drilled hole(s) for the lights. Insert wire(s) to the conduit(s) provided for the lights.

When ordering sauna room with NB heater, a dimmer switch is provided for the light(s).

When using NS heater, refer to the heater control instruction manual for the light installation.

Sauna Maintenance

AFTER EVERY SAUNA SESSION:

- ✓ It is recommended to use bench towels during sauna session to prevent sauna benches getting dirty.
- ✓ After sauna session, leave heater on for 30 minutes so sauna will dry faster. After that, open air vents or sauna door.
- ✓ Empty pail from water.

AT LEAST 1 -4 TIMES PER YEAR:

- ✓ Wash sauna surfaces with warm water and multi-purpose detergent. Use soft brush. Wash sauna benches, ceiling, floor and walls. Do not use detergent which includes ammonia or chlorine. Rinse surfaces with cold water and ventilate sauna room well. If needed, protect wood surfaces with wood treatment oil. Read carefully the instructions of wood treatment oil from product packaging.
- ✓ If sauna benches are not getting clean after washing, sand the benches with sandpaper. Protect benches with wood oil. Do not heat the sauna room straight after treatment.
- ✓ If there is calcium stains or other dirt on the heater cover, clean it with mild soap water. You can also use SAWO Decalcifying solution for washing the stains. Dry after wash.
- ✓ Clean glass surfaces with window cleaning agent or dish soap. Rinse well and dry with a squeegee or a dry cloth.
- Check screws (door, sauna benches, railings). Tighten up if necessary.
- ✓ Clean the floor drain.

Subject to change without notice.



www.sawo.com | info@sawo.com