



| Name | Outside Ø in. | Max bend radius in. | Ferrule | Min-Max T _a °F |
|------------|---------------|---------------------|-----------|---------------------------|
| S-Flex 1,5 | 0,1063 | 0,3937 | B1,5 / M5 | -58 - +356 |
| S-Flex 2 | 0,1496 | 0,5906 | B2 / M5 | -58 - +356 |

ENG The fibers may not be installed in less than +41°F ambient. If the fibers are stored in cold place, allow them to warm up for at least 2 h. before starting the installation.

Max bend radius

